

## **THE BLEEDING ON THE POWER BRAKE CYLINDERS**

The procedure to make the manual bleeding on the power brake cylinders is the following:

- The brake hoses should be without any air lock. Even one little air lock could cause problems as a vain brake pedal stroke.
- Keep the machine braked for 3-4 hours; the push rod should be adjusted in order to have the power brake cylinder on pressure.
- After 3-4 hours put the settlement of the push rod on a normal position.

Caution: the bleeding must be done with the power brake cylinder paced in a horizontal position eve if the fitting will be vertical.

**Note: this bleeding procedure should be observed for all kind of power brake cylinders.**