



BRAKES


BRAKE ASSY

STILL 170x40 Hub 72mm

Hand adjuster and parking brake

R60-16 R70-16

Cod.	Pos.	Description	Qty
MF201		Brake assembly RH	
MF202		Brake assembly LH	
PTC34	1	Plate RH	
PTC35	2	plate LH	
CF502B	3	Wheel cylinder	
GNF26	4	Brake shoe Neutral	
GNF27	5	Brake shoe Right lever	
GNF27/A	6	Brake shoe Left lever	
RGF121	7	Brake manual adjuster RH	
ML216	8	Brake spring	
ML215	9	Spring	
ML118	10	Spring pin	
ML117	11	Washer	
ML119	12	Brake spring	
ML514	13	Spring link	
ML515	14	Lever RH	
ML516	14	Lever LH	




STILL 180x40 Hub 72mm

Hand adjuster and parking brake

R50 R60-15

Cod.	Pos.	Description	Qty
MF203		Brake assembly RH	
MF204		Brake assembly LH	
PTC32	1	Plate RH	
PTC33	2	Plate LH	
CF502B	3	Wheel cylinder	
GNF24	4	Brake shoe Neutral	
GNF25	5	Brake shoe Right lever	
GNF25/A	6	Brake shoe Left lever	
RGF121	7	Brake manual adjuster RH	
ML216	8	Brake spring	
ML217	9	Spring	
ML118	10	Spring pin	
ML117	11	Washer	
ML119	12	Brake spring	
ML235	13	Spring link	
ML236	14	Lever	






BRAKES

BRAKE ASSY

STILL 200x45
R10


Cod.	Pos.	Description	Qty
MF378		Brake assembly RH	
MF379		Brake assembly LH	
GNF122	1	Brake shoe Neutral	
GNF121	2	Brake shoe Right lever	
GNF121/A	2	Brake shoe Left lever	
CF113	3	Wheel cylinder	
ML439	4	Spring	
ML440	5	Spring	




STILL 203x60 Hub 90mm
Auto adjuster and parking brake

R60-20-25

Cod.	Pos.	Description	Qty
MF205		Brake assembly RH	
MF206		Brake assembly LH	
PTC36	1	Plate RH	
PTC37	2	Plate LH	
CF502	3	Wheel cylinder	
GNF4	4	Brake shoe Neutral	
GNF3	5	Brake shoe Right lever	
GNF3/A	6	Brake shoe Left lever	
GNFK11	4-5-6	Brake shoe Complete kit	
RGF116	7	Brake auto adjuster	
ML218	8	Spring	
ML219	9	Spring	
ML458	10	Brake spring	
ML333	11	Lever	
ML334	12	Lever spring	
ML404	13	Washer	
ML335	14	Spring link	





BRAKES


BRAKE ASSY

STILL 203x60 Hub 85mm

Auto adjuster and parking brake

R60-20-25

Cod.	Pos.	Description	Qty
MF207		Brake assembly RH	
MF208		Brake assembly LH	
PTC38	1	Plate RH	
PTC39	2	Plate LH	
CF502	3	Wheel cylinder	
GNF4	4	Brake shoe Neutral	
GNF3	5	Brake shoe Right lever	
GNF3/A	6	Brake shoe Left lever	
GNFK11	4-5-6	Brake shoe Complete kit	
RGF117	7	Brake manual adjuster	
ML218	8	Spring	
ML458	9	Brake spring	
ML159	10	Brake spring	
ML333	11	Lever	
ML334	12	Lever spring	
ML404	13	Washer	
ML335	14	Spring link	




STILL 203x60 Hub 85mm

Auto adjuster and parking brake

R60-20-25

Cod.	Pos.	Description	Qty
MF211		Brake assembly RH	
MF212		Brake assembly LH	
PTC38	1	Plate RH	
PTC39	2	Plate LH	
CF502	3	Wheel cylinder	
GNF4	4	Brake shoe Neutral	
GNF3	5	Brake shoe Right lever	
GNF3/A	6	Brake shoe Left lever	
GNFK11	4-5-6	Brake shoe Complete kit	
RGF116	7	Brake auto adjuster	
ML218	8	Spring	
ML219	9	Spring	
ML458	10	Brake spring	
ML333	11	Lever	
ML334	12	Lever spring	
ML404	13	Washer	
ML335	14	Spring link	






BRAKES

BRAKE ASSY

STILL 260x60

Auto adjuster and parking brake

Cod.	Pos.	Description	Qty
MF346		Brake assembly RH	
MF347		Brake assembly LH	
PTC121	1	Plate RH	
PTC122	2	Plate LH	
CF117	3	Wheel cylinder	
RGF127	4	Brake manual adjuster RH	
RGF127/A	4	Brake manual adjuster LH	
GNFK6	5	Brake shoes kit with cable	
ML177	6	Adjuster cable	
ML317	7	Lever	
ML179	8	Drive cable	
ML318	9	Lever	
ML176	10	Lever	
ML103	11	Brake spring Right	
ML100	12	Brake spring Left	
ML102	13	Brake spring	
ML180	15	Link kit RH	
ML180/A	15	Adjuster link kit LH	
ML151	16	Brake spring	





STILL 270x60 Hub 130mm

Auto adjuster and parking brake

R60-30-35-40

Cod.	Pos.	Description	Qty
MF220		Brake assembly RH	
MF221		Brake assembly LH	
PTC56	1	Plate RH	
PTC57	2	Plate LH	
CF503	3	Wheel cylinder	
RGF118	4	Brake auto adjuster	
GNF10	5	Brake shoe neutral	
GNF9	6	Brake shoe Right lever	
GNF9/A	7	Brake shoe Left lever	
GNFK26	5-6-7	Brake shoe Complete kit	
ML133	8	Brake spring	
ML239	9	Brake spring	
ML155	10	Brake spring	
ML477	12	Lever	
ML478	13	Lever spring	
ML479	14	Washer	
ML480	18	Spring link	





BRAKES

BRAKE ASSY

STILL

Hand adjuster

Cod.	Pos.	Description	Qty
MF413		Brake assembly	
CF112	1	Wheel cylinder	
ML502	2	Brake spring	
ML501	3	Brake spring	

