




BRAKES

BRAKE ASSY

MITSUBISHI 310x60 Hub 100mm

Auto adjuster and parking brake


Cod.	Pos.	Description	Qty
MF264		Brake assembly RH	
MF264		Brake assembly RH	
MF265		Brake assembly LH	
RGF137	4	Brake manual adjuster RH	
GNF14	5	Brake shoe	
RGF137/A	4	Brake manual adjuster LH	
GNFK34	5	Brake shoes kit	
ML231	6	Adjuster cable	
ML165	7	Drive cable	
ML361	8	Lever RH	
ML361/A	8	Lever LH	
ML268	9	Spring RH	
ML268/A	9	Lever spring LH	
ML360	10	Bolt	
ML194	11	Spring link	
ML266	12	Brake spring	
ML294	13	Spring	
ML151	14	Brake spring	
ML101	15	Brake spring washer	



MITSUBISHI

Auto adjuster and parking brake

Cod.	Pos.	Description	Qty
MF266		Brake assembly RH	
MF267		Brake assembly LH	
PTC75	1	Plate RH	
PTC76	2	Plate LH	
CF132	3	Wheel cylinder	
RGF125	4	Brake manual adjuster RH	
RGF125/A	4	Brake manual adjuster LH	
GNF52	5	Brake shoe	
ML265	6	Adjuster cable	
ML165	7	Drive cable	
ML267	8	Lever RH	
ML267/A	8	Lever LH	
ML268	9	Spring RH	
ML268/A	9	Lever spring LH	
ML360	10	Bolt	
ML194	11	Spring link	
ML266	12	Brake spring	
ML253	13	Spring	
ML151	14	Brake spring	






BRAKES

BRAKE ASSY

MITSUBISHI 255x50 Hub 75mm

Auto adjuster and parking brake


Cod.	Pos.	Description	Qty
MF326		Brake assembly RH	
MF327		Brake assembly LH	
PTC79	1	Plate RH	
PTC80	2	Plate LH	
CF133	3	Wheel cylinder	
RGF135	4	Brake manual adjuster RH	
RGF135/A	4	Brake manual adjuster LH	
GNF18	5	Brake shoe	
GNFK35	5	Brake shoes kit	
ML109	6	Spring pin	
ML101	7	Brake spring washer	
ML151	8	Brake spring	
ML191	9	Lever RH	
ML192	9	Lever LH	
ML195	10	Lever	
ML264	11	Lever spring	
ML165	12	Drive cable	
ML296	13	Adjuster cable	
ML356	14	Lever	




MITSUBISHI 255x60 Hub 75mm

Auto adjuster and parking brake

Cod.	Pos.	Description	Qty
MF344		Brake assembly RH	
MF345		Brake assembly LH	
PTC81	1	Plate RH	
PTC82	2	Plate LH	
CF132	3	Wheel cylinder	
RGF137	4	Brake manual adjuster RH	
RGF137/A	4	Brake manual adjuster LH	
GNF14	5	Brake shoe	
GNFK34	5	Brake shoes kit	
ML269	6	Brake shoe lever RH	
ML269/A	6	Lever LH	
ML116	7	Spring pin	
ML101	8	Brake spring washer	
ML151	9	Brake spring	
ML266	10	Brake spring	
ML294	11	Spring	
ML361	12	Lever RH	
ML361/A	12	Lever LH	
ML268	13	Spring RH	





BRAKES

BRAKE ASSY

MITSUBISHI

Auto adjuster and parking brake

Cod.	Pos.	Description	Qty
MF402		Brake assembly RH	
MF403		Brake assembly LH	
PTC127	1	Plate RH	
PTC128	2	Plate LH	
CF132	3	Wheel cylinder	
RGF137	4	Brake manual adjuster RH	
RGF137/A	4	Brake manual adjuster LH	
GNF37	5	Brake shoe	
GNFK61	5	Brake shoes kit	
GNFK48	5	Brake shoes kit	
ML266	6	Brake spring	
ML194	7	Spring link	
ML294	8	Spring	
ML423	9	Adjuster cable	
ML297	10	Drive cable	
ML361	11	Lever RH	
ML361/A	11	Lever LH	
ML299	12	Spring adjuster lever Right	
ML299/A	12	Lever spring LH	

