




BRAKES

BRAKE ASSY

FENWICK


Hand adjuster and parking brake


Cod.	Pos.	Description	Qty
MF306		Brake assembly RH	
MF307		Brake assembly LH	
CF121.2	1	Wheel cylinder	
ML272	2	Spring	
ML273	3	Lever	
ML274	4	Spring	
GNFK21	5	brake shoes kit	
ML277	6	Spring	
ML379	7	Lever RH	
ML380	7	Lever LH	



FENWICK

Cod.	Pos.	Description	Qty
MF318		Brake assembly RH	
MF319		Brake assembly LH	
ML207	1	Spring	
ML208	2	Spring	
ML209	3	Brake spring	
ML210	4	Cup	
GNF42	5	Brake shoe	
ML211	6	Lever RH	
ML212	6	Lever LH	
CF128	7	Wheel cylinder	
ML213	8	Brake spring	
ML214	9	Adjuster	





BRAKES

BRAKE ASSY

FENWICK

With parking brake

Cod.	Pos.	Description	Qty
MF350		Brake assembly RH	
MF351		Brake assembly LH	
CF121	1	Wheel cylinder	
GNFK38	2	Brake shoes kit	
ML420	3	Spring kit	

